



1. Measure the length of the Smart® Band Flex you need and add at least 45 mm extra band. Insert 1 end of the strap into the buckle (SB-BU-FX-1/2-LH-POM) and allow it to protrude at least 2 mm.
2. Fit the strap around the object, including the application to be mounted, and slide the other end through the remaining opening in the buckle. Let it protrude at least 40 mm.
3. Place the tightening tool (SM-FT-2000-13-FX) on the long end and tighten the strap with the tool.
4. Remove the tightening tool and cut off the remaining part of the strap. Leave at least 2 mm of strap protruding from the buckle.